


## TN 98

### RACOR UNIÓN RECTO




REF.	DESCRIPCIÓN	ROSCA
750004LL	UNIÓN TN 98 4-LL	-
750005LL	UNIÓN TN 98 5-LL	-
750006LL	UNIÓN TN 98 6-LL	-
750008LL	UNIÓN TN 98 8-LL	-
750010LL	UNIÓN TN 98 10-LL	-
750012LL	UNIÓN TN 98 12-LL	-

REF.	DESCRIPCIÓN	ROSCA
750006S	UNIÓN TN 98 6-S	-
750008S	UNIÓN TN 98 8-S	-
750010S	UNIÓN TN 98 10-S	-
750012S	UNIÓN TN 98 12-S	-
750014	UNIÓN TN 98 14-S	-
750016	UNIÓN TN 98 16-S	-
750020	UNIÓN TN 98 20-S	-
750025	UNIÓN TN 98 25-S	-
750030	UNIÓN TN 98 30-S	-
750038	UNIÓN TN 98 38-S	-

REF.	DESCRIPCIÓN	ROSCA
750006L	UNIÓN TN 98 6-L	-
750008L	UNIÓN TN 98 8-L	-
750010L	UNIÓN TN 98 10-L	-
750012L	UNIÓN TN 98 12-L	-
750015	UNIÓN TN 98 15-L	-
750018	UNIÓN TN 98 18-L	-
750022	UNIÓN TN 98 22-L	-
750028	UNIÓN TN 98 28-L	-
750035	UNIÓN TN 98 35-L	-
750042	UNIÓN TN 98 42-L	-

## TN 98 R

### RACOR UNIÓN RECTO REDUCIDO



REF.	DESCRIPCIÓN	ROSCA
740604LL	UNIÓN TN 98 R 6LL- 4LL	-
740804LL	UNIÓN TN 98 R 8LL- 4LL	-
740806LL	UNIÓN TN 98 R 8LL- 6LL	-

REF.	DESCRIPCIÓN	ROSCA
740806S	UNIÓN TN 98 R 8S- 6S	-
741006S	UNIÓN TN 98 R 10S- 6S	-
741008S	UNIÓN TN 98 R 10S- 8S	-
741206S	UNIÓN TN 98 R 12S- 6S	-
741208S	UNIÓN TN 98 R 12S- 8S	-
741210S	UNIÓN TN 98 R 12S-10S	-
741410	UNIÓN TN 98 R 14S-10S	-
741412	UNIÓN TN 98 R 14S-12S	-
741612	UNIÓN TN 98 R 16S-12S	-
741614	UNIÓN TN 98 R 16S-14S	-
742010	UNIÓN TN 98 R 20S-10S	-
742012	UNIÓN TN 98 R 20S-12S	-
742016	UNIÓN TN 98 R 20S-16S	-
742516	UNIÓN TN 98 R 25S-16S	-
742520	UNIÓN TN 98 R 25S-20S	-
743020	UNIÓN TN 98 R 30S-20S	-
743025	UNIÓN TN 98 R 30S-25S	-
743825	UNIÓN TN 98 R 38S-25S	-
743830	UNIÓN TN 98 R 38S-30S	-

REF.	DESCRIPCIÓN	ROSCA
740806	UNIÓN TN 98 R 8L- 6L	-
741006	UNIÓN TN 98 R 10L- 6L	-
741008	UNIÓN TN 98 R 10L- 8L	-
741206	UNIÓN TN 98 R 12L- 6L	-
741208	UNIÓN TN 98 R 12L- 8L	-
741210	UNIÓN TN 98 R 12L-10L	-
741510	UNIÓN TN 98 R 15L-10L	-
741512	UNIÓN TN 98 R 15L-12L	-
741810	UNIÓN TN 98 R 18L-10L	-
741812	UNIÓN TN 98 R 18L-12L	-
741815	UNIÓN TN 98 R 18L-15L	-
742212	UNIÓN TN 98 R 22L-12L	-
742215	UNIÓN TN 98 R 22L-15L	-
742218	UNIÓN TN 98 R 22L-18L	-
742818	UNIÓN TN 98 R 28L-18L	-
742822	UNIÓN TN 98 R 28L-22L	-
743522	UNIÓN TN 98 R 35L-22L	-
743528	UNIÓN TN 98 R 35L-28L	-